


#4030 Modern Cantilever Signal Bridge Drill Template

Simply print this template at 100% size, glue it to a styrene square (roughly 1.5" X 1.5") and drill the holes as shown. We recommend drilling a single 1" diameter hole below the plastic base to ease the mounting process.

This 'base' will aid in moving the bridge should you wish to do so.



Drill Diameter: 3/16" (roughly .150")